

15 年防水性能系统

Resichem 552 CSM 防水涂层

产品为厚浆型，水基，丙烯酸防水涂层。
弹性防水漆膜用于屋顶，罐顶，及玻璃钢结构。

产品可涂覆于大部分基材表面，如，矿物毡，混凝土，玻璃钢，水泥板。固化后可在任何屋顶具备防水密封，抗紫外线，弹性漆膜性能。

产品特征

单层施工

极佳的延展性及弹性
刷涂，辊涂及喷涂

益处

性价比

长效防护性能

屋顶的15年以上防水性能

主要应用包括

大部分屋顶表面，
罐体屋顶，玻璃钢结构



工厂屋顶使用552 CSM 防水
薄膜搭配550 WR 防水涂层



552 CSM 防水薄膜涂层指南

施工	表面处理	底胶	层数	涂覆 552 CSM 防水薄膜涂层	增强产品
Mineral felt flat roof	Cut out and repair damaged/ blistered areas. Remove all loose chippings. Treat with fungicidal cleaner, pressure wash.	559 BP Primer applied 100 microns WFT	1	1 x coat of 552 CSM at 1000 microns WFT 1 x coat of 550 WR at 500 microns WFT	100gm glass fibre chop strand matting
Mineral felt roof pitched >15%	Cut out and repair damaged/ blistered areas. Remove all loose chippings. Treat with fungicidal cleaner, pressure wash.	559 BP Primer applied 100 microns WFT	1	1 x coat of 552 CSM at 1000 microns WFT 1 x coat of 550 WR at 500 microns WFT	Not needed
Asbestos flat roof	Cut out and repair damaged/ blistered areas. Treat with fungicidal cleaner, pressure wash.	559 BP Primer applied 100 microns WFT	1	1 x coat of 552 CSM at 1000 microns WFT 1 x coat of 550 WR at 500 microns WFT	100gm glass fibre chop strand matting
Previously coated flat roof	Remove any loose coating back to a sound edge. Treat with fungicidal cleaner, pressure wash.	506 Aluprime applied 150 microns WFT	1	1 x coat of 552 CSM at 1000 microns WFT 1 x coat of 550 WR at 500 microns WFT	100gm glass fibre chop strand matting
Previously coated roof pitched >15%	Remove any loose coating back to a sound edge. Treat with fungicidal cleaner, pressure wash.	506 Aluprime applied 150 microns WFT	1	1 x coat of 552 CSM at 1000 microns WFT 1 x coat of 550 WR at 500 microns WFT	Not needed
Plastisol cladding flat roof	Remove any loose coating back to a sound edge. Remove any flaking corrosion. Treat with fungicidal cleaner, pressure wash.	506 Aluprime applied 150 microns WFT	1	1 x coat of 552 CSM at 1000 microns WFT 1 x coat of 550 WR at 500 microns WFT	100gm glass fibre chop strand matting
Plastisol cladding flat roof >15%	Remove any loose coating back to a sound edge. Remove any flaking corrosion. Treat with fungicidal cleaner, pressure wash.	506 Aluprime applied 150 microns WFT	1	1 x coat of 552 CSM at 1000 microns WFT 1 x coat of 550 WR at 500 microns WFT	Not needed
Timber flat roof	Ensure timber is clean and dry (<5% moisture content)	503 SPEP applied 150 microns WFT	1	1 x coat of 552 CSM at 1000 microns WFT 1 x coat of 550 WR at 500 microns WFT	100gm glass fibre chop strand matting
Timber pitched roof >15%	Ensure timber is clean and dry (<5% moisture content)	503 SPEP applied 150 microns WFT	1	1 x coat of 552 CSM at 1000 microns WFT 1 x coat of 550 WR at 500 microns WFT	Not needed
GRP surfaces	Remove any loose coating back to a sound edge. Treat with fungicidal cleaner, pressure wash.	506 Aluprime applied 150 microns	1	1 x coat of 552 CSM at 1000 microns WFT 1 x coat of 550 WR at	100gm glass fibre chop strand matting